

JOB CARD

Vehicle Model		Reported Customer Concern			
2017 XE R-Sport		Auto Stop Start Not Available			
Vehicle Symptoms					
Area of Concern/Possible Causes					
Diagnostic Route / Tests					
Step	Description	Result	Fault Identified? (Y/N)		
1					
2					
3					
4					
5					
6					
7					
8					
9					
10					
Conclusion / Recommendations					

Activity – MultiCAN Operating Parameters

INSTRUCTION

OBJECTIVES: Gather MultiCAN network reference data.

ACTIVITY:

- Observe network operating values and behavior when the network is operating correctly.
- Record your observations and measured values.
- The activity involves the use of the PicoScope.
 - Instructions for setting the PicoScope are provided, however your trainer will assist you if you are unfamiliar with the use of the PicoScope
- If at any point you are unsure of the task instructions, please ask your trainer for assistance

TIME: 30 Minutes

Network Operating Voltage

INSTRUCTION

OBJECTIVES: Collect MultiCAN network operating voltages.

ACTIVITY:

- Use a multimeter to measure and record the network operating voltages.
- Ensure the vehicle ignition is switched on before any measurements are taken.
- Ensure a fully functioning, JLR approved battery charger/conditioner has been connected to the vehicle

Network	CAN High Voltage	CAN Low Voltage
BO – MSCAN		
CH – HSCAN		
CO – HSCAN		
PT – HSCAN		

High and Medium Speed Signals

INSTRUCTION

OBJECTIVES: To compare a High speed CAN signal to a Medium speed CAN signal.

ACTIVITY:

- Use the PicoScope to obtain a signal pattern for both a HS and a MS network. Ensure the vehicle ignition is switched on before any measurements are taken.
- Ensure a fully functioning, JLR approved battery charger/conditioner has been connected to the vehicle.
- Use the following settings for the PicoScope:
 - Channel A: Blue cable/scale – HS PT CAN High signal
 - Channel B: Red cable/scale – HS PT CAN Low signal
 - Channel C: Green cable/scale – MS BO CAN High signal
 - Channel D: Yellow cable/scale – MS BO CAN Low signal
 - Set the “y” axis voltage range for all four channels to +/- 10 Volts
 - Set the “x” axis or time-base to 100 us/div (micro-seconds per division).
 - Set the “y” axis offset to - 30% for channels C and D.
 - This will separate the CAN traces, making them clearer to observe.
- Ensure a suitable trace is displayed on all four channels.
- Stop the trace from running. Use the buffer frame navigation buttons to locate a good trace pattern which shows the start of both a MS and a HS message.
- Use the graphic E165628 to record your image. Use the NOTES table to record any observations.
- Study the PicoScope image to answer Question 1.